

Required amount of sealant per tire size

TERRA-S®

 = 450ml or 700ml bottle

 = 700ml bottle

Tire width in mm // Tire width in mm	Tire cross section												Wheel size in inches // Rim Size in Inch
	25	30	35	40	45	50	55	60	65	70	75	80	
130/ - 195/													R10 - R 13
135/													R 14
145/													
155/													
165/													
175/													
185/													
195/													
205/													
215/													
225/													
235/													R 15
245/													
135/													
145/													
155/													
165/													
175/													
185/													
195/													
205/													
215/													
225/													
235/													R 16
245/													
155/													
165/													
175/													
185/													
195/													
205/													
215/													
225/													
235/													
245/													

Required amount of sealant per tire size

TERRA-S®

 = 450ml or 700ml bottle

 = 700ml bottle

Tire width in mm // Tire width in mm	Tire cross section												Wheel size in inches // Rim Size in Inch
	25	30	35	40	45	50	55	60	65	70	75	80	
185/													R 17
195/													
205/													
215/													
225/													
235/													
245/													
255/													
265/													
275/													
285/													R 18
205/													
215/													
225/													
235/													
245/													
255/													
265/													
275/													
285/													
295/													R 19
205/													
215/													
225/													
235/													
245/													
255/													
265/													
275/													
285/													
225/													R 20
235/													
245/													
255/													
265/													
275/													
285/													
225/													R 21
235/													
245/													
255/													
265/													
275/													
285/													
295/													